

## W-Fly Radio System

### General Info:

- Channels are not listed on the receiver but the correct channel ports are Ch1 at the top and going down to Ch 4 at the bottom
- Orientation of the servo lead is labeled on the receiver

### LED Color Indication of Receiver:

- No Light = Ready
- Solid Red Light = Not Binded
- Flashing Orange Light = Bind Mode activated

### Bind Process:

- Everything should be off
- Connect the receiver to the plane and connect the battery to the plane
- Press and hold on to the "Set" button on the RX until LED is flashing orange then let go
- The RX should stay flashing orange
- Press onto and hold the "Set" button on the TX and power up the TX
- Let go of the "Set" button on the TX and immediately click the "Set" button once and the "Status" indicator on the TX should stay solid orange
- Press and hold the "Set" button on the TX once more until "Status" indicator goes solid green on the TX and at this point, the RX will automatically black out
- The TX should be a solid green light and the RX should have no light
- Bind process completed!



